


BOLON CARE+

CLEANING AND MAINTENANCE



IMPORTANT!

- Correctly performed maintenance prolongs the floor's useful life. Factors such as the colour and design of the floor as well as where the floor is installed affect the need for cleaning.
- We recommend vacuum cleaning for the daily cleaning.
- Always follow the machine's instructions.
- Incorrect use of the machine can damage the floor.

REGULAR CLEANING

- The floor should be cleaned mechanically at the frequency required by the environment.
- Small areas can be cleaned manually, see MANUAL CLEANING.

ZEROING

- A badly maintained floor, or a floor that has become extremely dirty for another reason, can be restored in most cases to an almost new condition, see ZEROING.

MECHANICAL CLEANING

THE ROLLER BRUSH METHOD

- Start by vacuum cleaning.
- Use a scrubber-dryer with soft brush rollers, warm water and the minimal dose of an all-purpose cleaner with a pH of 7-8.5, so the floor will not need rinsing afterwards. Clean the floor along the longitudinal direction if possible.

TO ZERO

- Start by vacuum cleaning.
- Remove any difficult stains, see STAIN REMOVAL.
- Use a scrubber-dryer with soft brush rollers, warm water and a strong, alkaline all-purpose cleaner with a pH of 9-11. Start by wetting the floor by running the machine with the brushes and water/heavy-duty cleaner solution. Do not use the suction function. Clean the floor along the longitudinal direction if possible.
- Leave to work for 5-10 minutes, without allowing it to dry.
- Then, rinse twice with clean water using the scrubber-dryer – or until it stops forming a lather.

THE ORBOT METHOD

- Start by vacuum cleaning.
- Use an Orbot machine with soft "SuperZorb" pads and warm water. Use a minimal dose of an all-purpose cleaner with a pH of 7-8.5 on more heavily soiled areas.
- Run the machine slowly backwards and forwards with uniform overlapping while "spray-damping" the floor. The dirt is absorbed in the pad. Replace the SuperZorb pad when it becomes too dirty or wet.

TO ZERO

- Start by vacuum cleaning.
- Remove any difficult stains, see STAIN REMOVAL.
- Use an Orbot machine with soft, Latex impregnated pad and warm water. If necessary, a strong, alkaline, all-purpose cleaner with a pH of 9-11 can be used on more difficult areas. Start by running the machine slowly backwards and forwards while "spray-damping" the floor. Work with uniform overlaps and "massage" the dirt loose using the AgiClean pad. The more difficult the dirt, the more the processing. Afterwards, suck up the dirt with the "SuperZorb" pads. To rinse afterwards, spray clean water and dry with dry terry cloth pads. For large areas, the after rinsing can be done using a scrubber-dryer.
- It is important that the floor be not allowed to dry, so the dirt dries on. For this reason, work on a smaller area, approx. 25m².
- In extremely dirty conditions, for example heavily trampled in dirt, the nylon brush may be appropriate to loosen the dirt. Afterwards, the dirt is sucked up according to the earlier description.

BOLON



MANUAL CLEANING

Manual cleaning may be performed on small areas and where you cannot reach with a machine.

REGULAR CLEANING

- Start by vacuum cleaning.
- Use a scrubbing brush, warm water and all-purpose cleaner with a pH of 7-8.5.
- Suck up the water with a wet vacuum cleaner or dry with soft cloth/micro-fibre cloth.

TO ZERO


- Start by vacuum cleaning.
- Remove any difficult stains, see STAIN REMOVAL.
- Use a scrubbing brush, warm water and an alkaline all-purpose cleaner with a pH of 9-11.
- Scrub the floor and leave to work for 5-10 minutes. Scrub it again and rinse with clean water. Dry up the water with a wet vacuum cleaner or a soft cloth/micro-fibre cloth.



STAIN REMOVAL

- It is best if the stain is treated at once.
- Check that the stain remover can be used on vinyl floor coverings.
- Use a scrubbing brush and rinse with water.

STAIN	CLEAN WITH
Chocolate, fat, juice, cream, coffee, beer, wine	Hot water with strong cleaner
Asphalt, oil, shoe cream, chalk, ink	Chemically pure petrol
Blood	Cold water – ammonia if needed
Rust	Light acidic (pH 3-4) cleaner
Water-based glue	Hot water
Solvent-based glue	Chemically pure petrol
Marks from shoes	Rub with dry cloth
Chewing gum	Hot steam or freeze spray



GENERAL ADVICE

- Think prevention! With an efficient entry system, you save your floor from 85 percent of all the incoming dirt.
- Choose the colour with care. Start from the surroundings where the floor will be used.
- Make sure all table and chair legs have furniture pads, no sharp edges and that they are made from stainless steel, polythene of similar.
- Prevent unnecessary wear and tear as well as discolouration by having hard polyamide chair wheels.
- Bolon's floor coverings are water resistant and are cleaned using wet methods.
- Do not use acetone or polish on Bolon's floor coverings.

BOLON

BOLON.COM
INFO@BOLON.COM | + 46 321 530 400
FACEBOOK.COM/BOLONFLOORING